

Using Oculus Quest and Oculus Go Cleaning Guidelines

It is important to promote hygiene and safety best practices when using Oculus Quest and Oculus Go across your workforce. Below, you will find recommended steps for cleaning your headset and hand controllers used for training, events, and other use cases, where the devices are shared by more than one person. Do not share headsets with persons with contagious conditions, infections, or diseases (for more information on health and safety, see [oculus.com/warnings](https://www.oculus.com/warnings)).

Cleaning Guidelines

- Wash your hands prior to using the headset and handling shared equipment. Use nitrile gloves while cleaning and dispose of gloves after each use. Between cleanings, either wash hands thoroughly or, if a sink is not readily accessible, use hand sanitizer. Wash hands thoroughly after each use.
- Clean devices (headset, controllers and other elements that people have touched) between each use with non-abrasive anti-bacterial wipes. Use a dry microfiber cloth to clean the lenses.
 - Note: Alcohol wipes should not be used on lenses but may be used on other headset components only. Alcohol wipes can damage lenses. Use with caution.
 - Be sure the products are non-abrasive.
- Let equipment completely air dry after cleaning before the next use. Use another headset or controller while the equipment fully air dries.
- Use a dry microfiber cloth (but not the same one used to wipe lenses as alcohol can damage lenses) to remove any wetness or residue from the headset and controllers.

Best Practices

- Use wipeable facial interfaces on headsets for which they are available (e.g., Oculus Quest and Oculus Go or for silicon surfaces). Wipe clean with non-abrasive, anti-bacterial wipes.
- For devices that do not have wipeable facial interfaces available, use barrier masks while following the same cleaning guidelines noted above between use. Replace and discard barriers after each use.